



ASQ CRE Prep course

Lesson V. C. Bonus

Acceleration Factors

AF use


- Acceleration factor is a ratio

$$AF = \frac{t_o}{t_s}$$


- For the Reliability Function

$$R_o(t) = R_s(t) \left(\frac{t}{AF} \right)$$

Graphically



Stress v Time to Failure



Again focus on
failure
mechanisms?



Work the Examples, too



Take another Sample Exam



Send over your questions



fms@accendoreliability.com



ASQ CRE Prep course



Module 7

VI. Maintainability and Availability